

A urethane clear formulated for spot, panel and overall repair. It will produce a high gloss fast dry finish with easy buffing that will perform with most basecoat systems.

PRODUCT	SIZE	ACTIVATOR	
PF 460	5 L (1.3 U.S. Gallon)	PF 461 Fast	2.5 L (0.7 U.S. Gallon)
		PF 462 Medium	2.5 L (0.7 U.S. Gallon)
		PF 463 Slow	2.5 L (0.7 U.S. Gallon)

READ ALL INSTRUCTIONS AND SAFETY PROCEDURES PRIOR TO USING!

IMPORTANT! This product contains hazardous materials.

Proper protective equipment should be used at all times. Please consult labels on each product as well as the safety data sheet for complete safe handling procedures and personal protection information.

NOTE: TEST ON A HIDDEN AREA BEFORE USING TO MAKE SURE THE PRODUCT PERFORMS TO YOUR SATISFACTION.

SUITABLE SUBSTRATES

- Automotive refinish basecoats (solvent based)
- Automotive refinish single stage (except acrylic lacquer)

ADVANTAGES

- High gloss
- Durable gloss
- Good flow out
- Easy buffing

SURFACE PREPARATION:

Apply basecoat as per manufacturer's mixing and application instructions. Allow sufficient flash times before applying Clearcoat. Inadequate flash time will affect the performance of this product.

MIXING DIRECTIONS:



2 parts of clearcoat PF 460 : 1 part of activator
Stir thoroughly between each addition. Strain before spraying material.

DIRECTIONS FOR USE:

For best results, use when temperature of the can and surface is between 21°C and 24°C (70°F and 75°F). This product is not recommended for use in temperatures below 16°C (60°F).

1. Read all label directions, warnings and cautions for safe usage.
2. Mix Clearcoat and activator as per instructions on label.
3. Stir thoroughly between each addition. Strain before spraying material.
4. Keep cap closed at all times, exposure to atmosphere can affect performance of this product.

Clean all spray equipment immediately after use.

SPRAY GUN AND PRESSURE:

<i>Gun Type</i>	<i>Tip</i>	<i>Air Pressure</i>
Siphon Feed	1.4-1.6 mm	35-45 psi
Gravity Feed	1.2-1.6 mm	25-40 psi
HVLP	1.2-1.6 mm	10 psi

Apply 2 full wet coats allowing 10 to 15 minutes flash time between coats or as conditions dictate. Caution: Do not apply over non catalyzed acrylic or synthetic enamels or acrylic lacquer finishes.

DRY TIMES:

All drying times refer to shop temperature of 20°C (68°F) / 50% humidity. Allow additional drying time when optimal conditions are not reached.

	PF 461 Fast	PF 462 Medium	PF 463 Slow
Dry to Touch:	10-15 minutes	10-15 minutes	15-20 minutes
Tack Free:	45-50 minutes	50-60 minutes	1-1.25 hours
Dry Through:	1-1.25 hours	1.5-2 hours	2-2.25 hours
Flash:	5-10 minutes	5-10 minutes	10-15 minutes
To Sand:	5-6 hours	5-6 hours	6-7 hours
To Buff:	5-6 hours	5-6 hours	6-7 hours
To Deliver:	Overnight	Overnight	Overnight

POT LIFE:

PF 461 Fast	PF 462 Medium	PF 463 Slow
1 hour	1.5 hours	1.5 hours

Note: Pot life will shorten as temperatures increase. Products are not recommended for use in temperature below 60°F(16°C).

FORCE DRYING:	Let the last coat flash for 20 minutes before baking. Bake at 60°C (140°F) for 20 minutes. Clearcoat may be wet sanded and buffed after 1 hour cool down time.
RECOATING:	Clearcoat may be recoated after a 24 hour dry time. Sand and then recoat.
FISH EYE:	The use of fish eye eliminator is not recommended.
CLEANING INSTRUCTIONS:	Clean equipment with lacquer thinner immediately after use.

Caution: It is important to test the compatibility of this product with your paint system. This product is not recommended for use in temperatures below 16°C (60°F). The use below these temperatures will affect dry times and performance.

TECHNICAL DATA:

Appearance:	Clear
Resin Type:	Acrylic Urethane
Reduction:	Up to maximum 10% Urethane Reducer
Flex Additive:	Not required
Film Build:	Maximum 6 mils wet, 2-2.5 mils dry

	PF 461 Fast	PF 462 Medium	PF 463 Slow
Weight Solids (R.T.S.):	41.95%	41.12%	41.12%
Volume Solids (R.T.S.):	38.91%	39.03%	38.80%
VOC (R.T.S.):	2.08 lbs/gal	2.08 lbs/gal	2.08 lbs/gal
Mixed Viscosity:	14" Zahn #2	13.5" Zahn #2	14" Zahn #2
Coverage @ sq.ft/gal:	624	626	622

PRECAUTIONARY INFORMATION

Refer to product label and Safety Data Sheet for health and safety information before using this product.

SAFETY CONSIDERATION

Safety Data Sheets are available at www.proformproducts.com or upon request at info@proformproducts.com. These are provided to help our customers satisfy their own handling, safety and disposal needs, and those required by local applicable health and safety regulations. Our Safety data sheets are updated regularly, therefore, please review the most current Safety Data Sheet before handling or using any product.

TECHNICAL INFORMATION

The technical information, recommendations and other statements contained in this document are based upon tests or experience that Pro Form believes are reliable, but the accuracy or completeness of such information is not guaranteed.

PRODUCT USE

Many factors beyond Pro Form's control and uniquely within user's knowledge and control can affect the use and performance of a Pro Form product in a particular application. Given the variety of factors that can affect the use and performance of a Pro Form product, user is solely responsible for evaluating the Pro Form product and determining whether it is fit for a particular purpose and suitable for user's method of application.

WARRANTY, LIMITED REMEDY, DISCLAIMER AND LIMITATION OF LIABILITY

Pro Form Products Ltd. ("Pro Form") makes no warranty, either express or implied, and specifically excludes any implied warranties or conditions of quality, whether of merchantability, fitness or otherwise. On any claim, irrespective of the legal theory invoked, Pro Form's total liability shall not exceed the purchase price of the product. At its option, Pro Form may instead replace or repair the product. In no event shall Pro Form be liable for any damages of any type, or for loss. The technical information, recommendations and other statements contained in this document are based upon tests or experience that Pro Form believes are reliable, but the accuracy or completeness of such information is not guaranteed.