

Body Filler Additive is designed to reduce pinholes and restore body filler to a creamy and smooth texture for easy application.

**PRODUCT**

**SIZE**

PF 153

473 ml (U.S. Pint)

**READ ALL INSTRUCTIONS AND SAFETY PROCEDURES PRIOR TO USING!**

**IMPORTANT! This product contains hazardous materials.**

Proper protective equipment should be used at all times. Please consult labels on each product as well as the safety data sheet for complete safe handling procedures and personal protection information.

**NOTE: TEST ON A HIDDEN AREA BEFORE USING TO MAKE SURE THE PRODUCT PERFORMS TO YOUR SATISFACTION.**

**ADVANTAGES:**

- Reduces pinholes
- Restores body fillers
- Easy application

**DIRECTIONS FOR USE:**

**RESTORING DRY BODY FILLERS:**

Mix filler thoroughly in can. Add ProLong a little at a time and mix until desired consistency is reached. Use normal amount of cream hardener.

**THINNING BODY FILLER FOR A FINISH COAT:**

1. Mix filler thoroughly in can. Remove desired amount.
2. Add PF 153 a little at a time and mix until desired consistency is reached.

**TECHNICAL DATA:**

	PF 153
Physical State	Liquid
Color:	Amber
Odour:	Aromatic
Solubility :	Slightly soluble in water
Flash point:	31°C (87.8°F)
Auto ignition temperature:	490°C (914°F)
VOC	131.8 g/l • 1.1 lbs/gal

**PRECAUTIONARY INFORMATION**

Refer to product label and Safety Data Sheet for health and safety information before using this product.

**SAFETY CONSIDERATIONS**

Safety Data Sheets are available at [www.proformproducts.com](http://www.proformproducts.com) or upon request at [info@proformproducts.com](mailto:info@proformproducts.com). These

are provided to help our customers satisfy their own handling, safety and disposal needs, and those required by local applicable health and safety regulations. Our Safety data sheets are updated regularly, therefore, please review the most current Safety Data Sheet before handling or using any product.

#### **TECHNICAL INFORMATION**

The technical information, recommendations and other statements contained in this document are based upon tests or experience that Pro Form believes are reliable, but the accuracy or completeness of such information is not guaranteed.

#### **PRODUCT USE**

Many factors beyond Pro Form's control and uniquely within user's knowledge and control can affect the use and performance of a Pro Form product in a particular application. Given the variety of factors that can affect the use and performance of a Pro Form product, user is solely responsible for evaluating the Pro Form product and determining whether it is fit for a particular purpose and suitable for user's method of application.

#### **WARRANTY, LIMITED REMEDY, DISCLAIMER AND LIMITATION OF LIABILITY**

Pro Form Products Ltd. ("Pro Form") makes no warranty, either express or implied, and specifically excludes any implied warranties or conditions of quality, whether of merchantability, fitness or otherwise. On any claim, irrespective of the legal theory invoked, Pro Form's total liability shall not exceed the purchase price of the product. At its option, Pro Form may instead replace or repair the product. In no event shall Pro Form be liable for any damages of any type, or for loss. The technical information, recommendations and other statements contained in this document are based upon tests or experience that Pro Form believes are reliable, but the accuracy or completeness of such information is not guaranteed.